


1. Speaker
2. Left selection button
3. Four-way navigation key
4. Camera shutter
5. Call button
6. End call button
7. International prefix
8. Symbols
9. Left selection button
10. Right selection button
11. Message shortcut
12. Call log
13. End call/Power on/off
14. Silent mode



14. Camera flash and lens
15. Red light - Battery level low / Charging
16. Green light - Name message / missed call
17. Camera lens
18. Assistant button
19. Headset socket
20. Charging socket
21. External microphone
22. Loudspeaker
23. Volume keys

Notes: All illustrations are for illustrative purposes only and may not accurately depict the actual device.
The items supplied with your phone might vary depending on the software and accessories available in your region or offered by your service provider. You can obtain additional accessories from your local Doro-Store. The supplied accessories provide the best performance with your phone.

IMPORTANT!

Your device uses data services and also may incur charges for data services, such as messaging or using location services depending on your data plan. We recommend that you check your data rates for your subscription with your service provider.

1. GET STARTED

When you find get your phone, there is a few actions that you need to take before starting to use it.

Tip: Remove the plastic screen protector.

1.1. Unbox your new phone

The first step is to unbox the phone and access the items and equipment included in the delivery. Make sure to read through the manual so you can familiarize yourself with the equipment and the basic functions. For the full manual please visit www.doro.com or contact us helpdesk.

- The items supplied with the device and any available accessories may vary depending on the region or service provider.
- The supplied items are designed only for this device and may not fit completely with other devices and accessories.
- Accessories and specifications are subject to change without prior notice.
- You can purchase additional accessories from your local Doro-Store.
- Make sure they are compatible with the device before purchase.

- Only use batteries, chargers and accessories that have been approved for use with this particular model. Connecting other accessories may be dangerous and may invalidate the phone's warranty and warranty.
- Availability of all accessories is subject to change depending entirely on manufacturing companies, the phone indicates about available accessories, refer to the Doro website.

Insert the memory card, SIM card and battery

Important! Turn off the phone and disconnect the charger before inserting the battery cover.

Remove the battery cover:

Important! Be careful not to damage your fingernails when you remove the battery cover. Do not bend or twist the battery cover excessively as it may get damaged.



Insert the SIM card:

Notes: You can not insert a SIM card or bend the contacts on the card when inserting them into the card holder.
Insert the Micro-SIM or UICC card (provided by the mobile service provider). Make sure that the flat part of the card is facing upwards (the gold contacts) and that the cut off corner is an arrow.
Should you need, but have problems to remove/change the SIM card, use adhesive tape on the exposed part of the SIM card to pull it out.

Insert the memory card:
You may optionally insert a memory card to the phone to increase the storage space of your phone for able to store more files, photos, videos etc. Make sure that the memory card's contacts are facing downwards, as shown below.
Notes: This device only accepts micro-SIM card (MIF). Use of incompatible SIM cards may damage the card or the device, and may corrupt data card.
Use only compatible memory cards with this device. Compatible card types include microSD, microSDHC, microSDXC. Incompatible memory cards may damage the card itself, the device and corrupt any data stored on the card.

Insert the battery:

Insert the battery by sliding it into the battery compartment with the contacts facing upwards to the left.
Replace the battery cover.

1.2. Charge

While it's possible that your phone will already come with enough charge to get powered on right out of the box, we recommend to give it a full charge before first use.

Caution: Only use batteries, chargers and accessories that have been approved for use with this particular model. Connecting other accessories may be dangerous and may invalidate the phone's warranty and warranty.
When the battery is running low, a red light appears, and a warning signal is heard. Connect the device adapter to a wall socket and to the charging socket. To place the device in a charging cable.
Alternatively connect the cable to the charging socket on the phone to a USB port on a computer.

1.3. Save energy

When the battery is fully charged, disconnect the charger from the device and unplug the charger from the wall socket.

To save power the screen goes off after a while. Press any button to wake the screen up. Buttons disappear over time, which means that call time and standby time will naturally decrease with regular use. During extended operation, the device may heat up, in most cases, this is normal. To avoid getting too warm, the device may switch off during charging.

1.4. Turn the phone on and off

1. Press and hold the red button (End call/Power on/off) for 5 seconds to turn the phone on.
2. If the SIM card is valid but protected with a PIN code (Personal Identification Number) the PIN code is displayed. Enter the PIN code and press OK. Confirm with OK (2000 right selection button).

Notes: (PIN) and (PUK) codes were not provided with your SIM card, please contact your service provider.

If it is recommended to remove the protection (PIN) from the display to protect the security.

Warning: If shows the number of PIN attempts left. When the maximum attempts remain, PIN blocked is displayed. The SIM card must be re-activated with the PUK code (Personal Unblocking Key).

1. Enter the PUK code and confirm with OK.
2. Enter a new PIN code and confirm with OK.
3. Re-enter the new PIN code and confirm with OK.

2. GET TO KNOW YOUR PHONE

When starting the telephone for the first time, you are guided by the Start-up wizard to set some basic settings. Select the setting you would like to change.

When ready, scroll to the end and press Back.

2.1. Descriptions in this document

Descriptions in this document are based on (real phone's) setup at the time of purchase. Buttons names normally start with the phone screen. Press (Back) (Left) to reach the home screen. Setting descriptions are provided.

The arrow (→) indicates main action in step-by-step (tutorial) form.

2.2. Handle the phone

Selection buttons (OK):
The selection buttons have multiple functions. The current key function is shown above the selection button on the display.

Contacts (→):
Press to see more options available in selected menu. This is displayed as the left selection button is selected.

Back (←):
Return to the previous screen. This is displayed as the right selection button is selected.

Call (→):

- Call a number or contact an incoming call.
- Enter the call log.
- End call/Power on and off (→):**
• Press to end calls or return to the home screen.
- Long press to power on or off.
- Assistance (→):**
• Press to make an assistance call.
- Camera (→):**
• Activate the camera app.
- Message (→):**
• Press to initiate the messaging app.

Navigation keys:

1. (OK) Use the Four-way navigation key to navigate up, down, left or right. These keys will be shown as (→) on the rest of this document.
2. (OK) Use the center button to open the main menu, select the menu and open an item. This button will be shown as (OK) in the rest of this document.



Notes: Navigation in some third-party apps might work differently.

Volume control:

The buttons on the side of the device to adjust the sound volume. During a phone call, it adjusts the speaker volume.

Set the language:

The default language is determined by the SIM card.
Press (OK) → Settings → General → Language settings → Default language

Set the time and date:

The time and date are automatically set from the network.
Press (OK) → Settings → General → Time & date

2.3. Enter text

- Press the button corresponding to the letter used the appropriate character appears.
- Press (OK) for a list of repeated characters. Select the desired character using the Four-way navigation key and press OK to enter it.
- Use the Four-way navigation key to move the cursor within the text.
- Press Clear to erase characters.
- Press (OK) to select upper case (MNC), lower case (mnc), symbols (sym), numbers (123) and predictive text (language code).

Enter text with predictive text:

In some languages you can use the predictive text input method with text is actually present in suggested words, and press the button corresponding to the appropriate

character and then select the suggested word with (OK) and confirm the selected word with OK.

Change the writing language:

1. Press (OK) and select the language for a list of available languages.
2. Select language and press OK to confirm.

Enter phone numbers:

Notes: For international calls, always use a before the country code for first application. Press (OK) before for the international prefix.
You can dial or save phone numbers with areas for use with automated systems, such as automated or credit card billing numbers. There are two types of numbers available on your phone, press (OK) repeatedly until desired character is shown. For first part and OK to be valid for later activation.

2.4. External display

Display the date, the time and notifications.

3. CALLS

3.1. Make a call

1. Enter the phone number.
2. Press (→) (green) to call.
3. Press (→) (red) to end the call.

Notes: There is no dial tone. As long as the phone is turned on, it is ready for use.

3.2. Make a call from the contacts list

1. Press (→).
- Alternatively, press OK → Contacts.
2. Use (→) to scroll through the contacts, or press (OK) → Search (→) to search the phonebook.
3. Select the contact and press (→) (green).
- Alternatively, select the wanted contact and press OK → (→) → Call to select a secondary number stored in that contact.

3.3. Receive a call

1. In a ringing call when the phone is closed, open the phone.
- Press (→) (green) to answer.
- Alternatively, press (→) to switch off the ringtone on the screen and press (→) to reject directly (Silent reject).

Silence an incoming call

1. When a call comes in, press any of the volume keys to silence the ring tone.

3.4. Call log

Received, missed, and dialled calls are saved in a call log.

Retrieving and dialling:

1. Press (→) (green).
2. Use (→) to scroll through the call log.
- (→) = Incoming call
- (→) = Outgoing call
- (→) = Missed call
3. Press (→) (green) to dial the highlighted number.

4. CONTACTS

4.1. Create a contact

1. Press OK → Contacts → Add → select the wanted storage (Phone/Email)
2. Enter relevant contact information.
3. When done, press Save.

Tip: Depending on the selected storage location, the type of information you can save may vary.

4.2. Create ICE entry (In Case of Emergency)

First responders can access additional information such as medical information from the victim's phone in case of emergency. In the event of a trauma, it is critical to have this information as early as possible to increase the efficacy of medical aid. ICE fields are optional, but the more information provided the better.

1. Press OK → Contacts → ICE.
2. Fill in as much information as possible.
3. Select information field and press Edit, press Save when done.

5. SOS/112 CALLS

As long as the phone is switched on, it is always possible to place an SOS call by entering the main local emergency number for your preferred location followed by (→) (green). Some networks accept calls to emergency numbers without a valid SIM card. Contact your service provider for more information.

Notes: Sometimes an emergency call cannot be placed due to network, environment or interference issues.

6. ASSISTANCE BUTTON (→)

Important: Please note that if the Assistance call is answered by a voice mail or answering machine, the phone will be disconnected and no further call attempts will be made (assistance sequence interrupted).
The Assistance button on the back of the phone allows easy access to your preselected help contacts (person) in case of emergency. Before use that the assistance function is activated before use.

See the full manual for more information about the function.

6.1. Activation

Activate the function for the assistance button.

1. Press OK → Assistance → Activation.
• On normal is pressed and hold the button for approximately 1 seconds, or press it twice within 1 second.
- On (OK) to press the button. It turns within 1 second.
- Off to disable the assistance button.

6.2. Helpers

Assign contacts (helpers) to the list that are called when the assistance button is pressed.

1. Press OK → Assistance → Helpers.
2. Select Add → Manual to add names/numbers manually. Alternatively, press Contacts to add a contact from the contacts.
3. Press (→) to go back and continue with other settings.

6.3. Assistance SMS

A text message can be sent to the helpers when the assistance button is pressed.

1. Press OK → Assistance → Assistance SMS.
2. Check Assistance SMS to activate the feature.
3. Go down to the message field and write the message.
4. Press Save to save the message.

Press (→) to go back and continue with other settings.
Notes: If you send a message if you activate the assistance SMS feature, it is helpful for the recipient of the assistance message if you indicate that it's an assistance alert and that it's from your phone.

Always inform helpers in the helpers list that they are listed as your assistance contacts.

Example: "This is an emergency message from John Smith."

6.4. Signal type

Select the notification signal type for the assistance sequence.

1. Press OK → Assistance → Signal type.
• High to use loud signals (default).
- Low to use low signal.
- Silence sound indication, like a normal call.

2. Press (→) to go back and continue with other settings.

Brush A30 Manual

John Francis Rider



Brush A30 Manual:

If you ally infatuation such a referred **Brush A30 Manual** books that will allow you worth, acquire the totally best seller from us currently from several preferred authors. If you desire to witty books, lots of novels, tale, jokes, and more fictions collections are plus launched, from best seller to one of the most current released.

You may not be perplexed to enjoy all books collections Brush A30 Manual that we will utterly offer. It is not on the costs. Its roughly what you infatuation currently. This Brush A30 Manual, as one of the most effective sellers here will entirely be in the course of the best options to review.

<https://stats.tinkerine.com/public/book-search/index.jsp/apprendre%20lallemand%20bilingue%20fran%20ais%20aventures.pdf>

Table of Contents Brush A30 Manual

1. Understanding the eBook Brush A30 Manual
 - The Rise of Digital Reading Brush A30 Manual
 - Advantages of eBooks Over Traditional Books
2. Identifying Brush A30 Manual
 - Exploring Different Genres
 - Considering Fiction vs. Non-Fiction
 - Determining Your Reading Goals
3. Choosing the Right eBook Platform
 - Popular eBook Platforms
 - Features to Look for in an Brush A30 Manual
 - User-Friendly Interface
4. Exploring eBook Recommendations from Brush A30 Manual
 - Personalized Recommendations
 - Brush A30 Manual User Reviews and Ratings
 - Brush A30 Manual and Bestseller Lists

5. Accessing Brush A30 Manual Free and Paid eBooks
 - Brush A30 Manual Public Domain eBooks
 - Brush A30 Manual eBook Subscription Services
 - Brush A30 Manual Budget-Friendly Options
6. Navigating Brush A30 Manual eBook Formats
 - ePub, PDF, MOBI, and More
 - Brush A30 Manual Compatibility with Devices
 - Brush A30 Manual Enhanced eBook Features
7. Enhancing Your Reading Experience
 - Adjustable Fonts and Text Sizes of Brush A30 Manual
 - Highlighting and Note-Taking Brush A30 Manual
 - Interactive Elements Brush A30 Manual
8. Staying Engaged with Brush A30 Manual
 - Joining Online Reading Communities
 - Participating in Virtual Book Clubs
 - Following Authors and Publishers Brush A30 Manual
9. Balancing eBooks and Physical Books Brush A30 Manual
 - Benefits of a Digital Library
 - Creating a Diverse Reading Collection Brush A30 Manual
10. Overcoming Reading Challenges
 - Dealing with Digital Eye Strain
 - Minimizing Distractions
 - Managing Screen Time
11. Cultivating a Reading Routine Brush A30 Manual
 - Setting Reading Goals Brush A30 Manual
 - Carving Out Dedicated Reading Time
12. Sourcing Reliable Information of Brush A30 Manual
 - Fact-Checking eBook Content of Brush A30 Manual
 - Distinguishing Credible Sources
13. Promoting Lifelong Learning

- Utilizing eBooks for Skill Development
- Exploring Educational eBooks

14. Embracing eBook Trends

- Integration of Multimedia Elements
- Interactive and Gamified eBooks

Brush A30 Manual Introduction

In the digital age, access to information has become easier than ever before. The ability to download Brush A30 Manual has revolutionized the way we consume written content. Whether you are a student looking for course material, an avid reader searching for your next favorite book, or a professional seeking research papers, the option to download Brush A30 Manual has opened up a world of possibilities. Downloading Brush A30 Manual provides numerous advantages over physical copies of books and documents. Firstly, it is incredibly convenient. Gone are the days of carrying around heavy textbooks or bulky folders filled with papers. With the click of a button, you can gain immediate access to valuable resources on any device. This convenience allows for efficient studying, researching, and reading on the go. Moreover, the cost-effective nature of downloading Brush A30 Manual has democratized knowledge. Traditional books and academic journals can be expensive, making it difficult for individuals with limited financial resources to access information. By offering free PDF downloads, publishers and authors are enabling a wider audience to benefit from their work. This inclusivity promotes equal opportunities for learning and personal growth. There are numerous websites and platforms where individuals can download Brush A30 Manual. These websites range from academic databases offering research papers and journals to online libraries with an expansive collection of books from various genres. Many authors and publishers also upload their work to specific websites, granting readers access to their content without any charge. These platforms not only provide access to existing literature but also serve as an excellent platform for undiscovered authors to share their work with the world. However, it is essential to be cautious while downloading Brush A30 Manual. Some websites may offer pirated or illegally obtained copies of copyrighted material. Engaging in such activities not only violates copyright laws but also undermines the efforts of authors, publishers, and researchers. To ensure ethical downloading, it is advisable to utilize reputable websites that prioritize the legal distribution of content. When downloading Brush A30 Manual, users should also consider the potential security risks associated with online platforms. Malicious actors may exploit vulnerabilities in unprotected websites to distribute malware or steal personal information. To protect themselves, individuals should ensure their devices have reliable antivirus software installed and validate the legitimacy of the websites they are downloading from. In conclusion, the ability to download Brush A30 Manual has transformed the way we access information. With the convenience, cost-effectiveness,

and accessibility it offers, free PDF downloads have become a popular choice for students, researchers, and book lovers worldwide. However, it is crucial to engage in ethical downloading practices and prioritize personal security when utilizing online platforms. By doing so, individuals can make the most of the vast array of free PDF resources available and embark on a journey of continuous learning and intellectual growth.

FAQs About Brush A30 Manual Books

What is a Brush A30 Manual PDF? A PDF (Portable Document Format) is a file format developed by Adobe that preserves the layout and formatting of a document, regardless of the software, hardware, or operating system used to view or print it.

How do I create a Brush A30 Manual PDF? There are several ways to create a PDF: Use software like Adobe Acrobat, Microsoft Word, or Google Docs, which often have built-in PDF creation tools. Print to PDF: Many applications and operating systems have a "Print to PDF" option that allows you to save a document as a PDF file instead of printing it on paper. Online converters: There are various online tools that can convert different file types to PDF.

How do I edit a Brush A30 Manual PDF? Editing a PDF can be done with software like Adobe Acrobat, which allows direct editing of text, images, and other elements within the PDF. Some free tools, like PDFescape or Smallpdf, also offer basic editing capabilities.

How do I convert a Brush A30 Manual PDF to another file format? There are multiple ways to convert a PDF to another format:

Use online converters like Smallpdf, Zamzar, or Adobe Acrobats export feature to convert PDFs to formats like Word, Excel, JPEG, etc. Software like Adobe Acrobat, Microsoft Word, or other PDF editors may have options to export or save PDFs in different formats.

How do I password-protect a Brush A30 Manual PDF? Most PDF editing software allows you to add password protection. In Adobe Acrobat, for instance, you can go to "File" -> "Properties" -> "Security" to set a password to restrict access or editing capabilities.

Are there any free alternatives to Adobe Acrobat for working with PDFs? Yes, there are many free alternatives for working with PDFs, such as: LibreOffice: Offers PDF editing features. PDFsam: Allows splitting, merging, and editing PDFs. Foxit Reader: Provides basic PDF viewing and editing capabilities.

How do I compress a PDF file? You can use online tools like Smallpdf, ILovePDF, or desktop software like Adobe Acrobat to compress PDF files without significant quality loss. Compression reduces the file size, making it easier to share and download.

Can I fill out forms in a PDF file? Yes, most PDF viewers/editors like Adobe Acrobat, Preview (on Mac), or various online tools allow you to fill out forms in PDF files by selecting text fields and entering information.

Are there any restrictions when working with PDFs? Some PDFs might have restrictions set by their creator, such as password protection, editing restrictions, or print restrictions. Breaking these restrictions might require specific software or tools, which may or may not be legal depending on the circumstances and local laws.

Find Brush A30 Manual :

[apprendre l'allemand bilingue français aventures](#)

aprilia mana user manual

aprilia scarabeo 500 2003 2011 factory service repair manual

applying career development theory counseling

aprilia rst mille futura 2002 repair service manual

aqa gcse geography revision guide

apprenez respirer vos enfants ebook

[aprilia leonardo 250 300 2000 2004 repair service manual](#)

[aprilia v990 motorcycle service repair manual](#)

[apraxia goals for therapy](#)

aprilia atlantic 125 200 factory service repair manual

[aprilia parts manual](#)

~~aprilia rs 125 1993 2006 full service repair manual~~

approaching zion the collected works of hugh nibley vol 9

aprenda a usar windows 8 a fondo

Brush A30 Manual :

Advanced Placement - CEE - Council for Economic Education AP Macroeconomics Student Workbook 5th Edition. \$29.95. AP Macroeconomics Teacher Guide 5th Edition. \$41.95. AP Microeconomics Student Workbook 5th Edition. Advanced Placement Economics: Teacher Resource Manual 1. Advanced Placement Economics: Teacher Resource Manual Use this powerful teacher guide to support your existing AP Economics curriculum. Unit plans give you a ... Macroeconomics: Teacher Resource Manual: Ray ... Advanced Placement Macroeconomics is the go-to guide for helping high school teachers to prepare their students for the AP Macroeconomics Exam administered ... Advanced Placement Economics. Teacher Resource Manual This book, in conjunction with the student activities books for macroeconomics and microeconomics, is designed for teaching the Advanced Placement Economics ... Macroeconomics: Teacher Resource Manual (Paperback) Advanced Placement Macroeconomics is the go-to guide for helping high school teachers to prepare their students for the AP Macroeconomics Exam administered ... Advanced Placement Economics: Teacher Resource Manual The teacher guide accompanies the student activities books in macro and microeconomics for teaching collegelevel economics in AP Economics courses.

Advanced Placement Economics - Macroeconomics ... Advanced Placement Macroeconomics is the go-to guide for helping high school teachers to prepare their students for the AP Macroeconomics Exam administered ... AP Macroeconomics Archives If the answer to these questions, is yes, then CEE's AP Macroeconomics Teacher Resource Manual with accompanying Student Resource Manual (4th Edition) is the go ... Macroeconomics: Teacher Resource Manual book ... Buy a copy of Advanced Placement Economics - Macroeconomics: Teacher Resource Manual book by Margaret A. Ray. Advanced placement economics : teacher resource manual May 6, 2022 — xix, 694 pages ; 28 cm. Essentials of Abnormal Psychology Essentials of Abnormal Psychology. 7th Edition. ISBN-13: 978-1305633681, ISBN ... Fundamentals of Abnormal Psychology Fundamentals of Abnormal Psychology becomes the first abnormal psychology ... Worth Publishers; Seventh edition (March 11, 2013). Language, English. Paperback ... Bundle: Essentials of Abnormal Psychology, ... Revised to reflect DSM-5, this briefer version of Durand and Barlow's widely used book fully describes abnormal psychology through the authors' ... Essentials of Abnormal Psychology 7th edition Essentials of Abnormal Psychology 7th Edition is written by V. Mark Durand; David H. Barlow and published by Cengage Learning. The Digital and eTextbook ... Essentials of Abnormal Psychology | Rent | 9781305094147 The original list price of Essentials of Abnormal Psychology 7th Edition (9781305094147) is around \$240 which could feel like a lot for a 3.45 pound book. Essentials of Abnormal Psychology 7th Edition Books; Essentials of Abnormal Psychology. Essentials of Abnormal Psychology. by Vincent Mark Durand, David H. Barlow. Essentials of Abnormal Psychology. by ... eTextbook: Essentials of Abnormal Psychology, ... eTextbook: Essentials of Abnormal Psychology, 7th Edition ; Starting At \$74.95 ; Overview. EPUB EBK: ESSENTIALS OF ABNORMAL PSYCHOLOGY. Read More ; RETAIL \$74.95. Essentials of Abnormal Psychology 7th Find 9781305633681 Essentials of Abnormal Psychology 7th Edition by Durand et al at over 30 bookstores. Buy, rent or sell. Essentials of Abnormal Psychology (MindTap Course List) ... Essentials of Abnormal Psychology (MindTap Course List) (7th Edition). by Vincent Mark Durand, David H. Barlow. Hardcover, 704 Pages, Published 2015. Essentials of Abnormal Psychology Vincent Mark ... Essentials of Abnormal Psychology Vincent Mark Durand, Barlow, David 7th edition ; Publication Year. 2016 ; Type. Textbook ; Accurate description. 5.0 ; Reasonable ... BowFlex Product Manuals Misplace your owner's manual? Look no further. Assembly instructions, owners manuals and quick-start guides for BowFlex exercise machines. SOLVED: Instructions for Bowflex WR30M? Apr 13, 2012 — Need Directions for Use for settings for Bowflex WR30M Watch & Wireless Heart - Watches question. ... Full user manual and instructions there to ... Bowflex Wr30m Watch Manual Bowflex Wr30m Watch Manual. Downloaded from web.mei.edu by guest. HOBBS ANTON. Related with Bowflex Wr30m Watch Manual: • Argument Writing Graphic Organizer. Salutron BOWFLEX User Manual View and Download Salutron BOWFLEX user manual online. Strapless Heart Rate Watch & Pedometer. BOWFLEX fitness trackers pdf manual download. Bowflex Heart Rate Monitor WR30m WR30m user manual Oct 3, 2013 — Manuals and free owners instruction pdf guides. Find the user manual and the help you need for the products you

own at ManualsOnline. Bowflex WR30M manual Sep 4, 2013 — Instructions for Bowflex WR30M? In time mode, hold set (bottom right button) to change date and time. The selected (flashing) item can be ... Bowflex Heart Rate Monitor Product Support | ManualsOnline ... I need a manual or instructions for the WR30M watc. Bowflex Heart Rate Monitor wr30m. 0 Solutions. I have a Bowflex watch. And the pulse feature stop. Bowflex ... Amazon.com: Customer Questions & Answers Bowflex Classic Strapless Heart Rate Monitor Watch (Black). Customer Questions ... Q: I have bowflex wr30m.i need instructions how to set everthing. I have a ... WR30 M | PDF | Business INSTRUCTIONS watch face or on the caseback. SPECIAL EXTENDED SPECIAL EXTENDED • Water-Resistant watch withstands water pressure to 60 p.s.i.a.. WARRANTY OFFER ...